



1




Make sure your garment is clean and completely dry. It is recommended to wash garment before application of transfer. Iron the area where transfer is to be applied. It is only recommended that garment be ironed on a surface designed for such an activity.

2




Remove and discard white protective paper. This will leave transfer and clear release paper. Position transfer over garment with the tacky side facing down. Transfer will not adhere until heat has been applied to it. Try to avoid positioning transfer over seams and hems as transfer could to lift over time.

3




Iron transfer firmly with your iron set to "Cotton". Iron for between 5 to 30 seconds, depending on how large your transfer is. Make sure that the iron passes over all areas of transfer. It is normal for the release liner to distort and start to lift at this stage. Ensure that all areas of the transfer have been ironed.

4




It is easier to remove release liner while it is still warm. Release liner will be hot directly after it has been ironed. Allow to cool for 20 to 30 seconds before handling. Whilst keeping fabric taught with one hand, remove release liner, ensuring to take care around fine detail and edges of transfer.

5



If ironing onto softer fabric, it may be necessary to place hand as close to the area where the release film is being removed from to ensure no stretching occurs. If transfer begins to lift in areas, place the release liner over transfer and re-iron affected area for 5 - 10 seconds. After use, re-ironing using a pillow case or linen will re-affix transfer.

6



Garment can be worn as normal. User should wash garment by following the manufacturer's instructions as detailed on the garment's label. Transfer can be tumble dried on a medium heat setting. It is not recommended that the transfer be ironed after application. Thank You. Enjoy your Wearable Words!

INSTRUCTIONS